Shure Performance Gear UHF and UT Series Wireless Frequency Compatibility Chart

(581.200-624.300 MHz, 740.375-751.875 MHz, 774.400-781.775 MHz)

Shure Performance Gear UHF and UT Series Wireless Systems in the United States are available in 27 frequencies between 581.200 MHz and 781.775 MHz. Up to 8 Shure Performance Gear UHF and UT Series Wireless Systems can be operated simultaneously in a single location using the following compatibility groups. Compatibility groups are defined as sets of compatible frequencies. To ensure compatibility, all systems in a given location must be within the same Group. Frequencies across multiple groups may or may not be compatible. Contact Shure Incorporated if you need additional information or assistance in frequency selection and setup.

If TV Channels 35, 36, 37, & 39 are open / available use the following frequency codes. (All are compatible)			
Compatibility Group 1			This frequency is in US TV Channel:
TE	598.625	MHz	TV 35
TF	600.800	MHz	TV 35
TC	603.900	MHz	TV 36
TD	606.300	MHz	TV 36
TG	615.900	MHz	TV 38
TH	617.100	MHz	TV 38
TJ	623.350	MHz	TV 39
TK	624.300	MHz	TV 39

If TV Channels 59 & 60 are open / available, use the following frequency codes. (All are compatible)			
Compatibility Group 2			This frequency is in US TV Channel:
٧E	740.375	MHz	TV 59
٧F	742.125	MHz	TV 59
۷G	744.875	MHz	TV 59
VH	746.375	MHz	TV 60
٧J	748.875	MHz	TV 60
٧K	751.875	MHz	TV 60

If TV Channels 64 & 65 are open / available, use the following frequency codes. (All are compatible)				
Compatibility Group 3			This frequency is in US TV Channel:	
٧L	774.400	MHz	TV 64	
VM	776.150	MHz	TV 65	
VN	780.400	MHz	TV 65	
VQ	781.775	MHz	TV 65	

If TV Channels 32& 33 are open / available, use the following frequency codes. (All are compatible)			
Compatibility Group 4			This frequency is in US TV Channel:
FH	581.200	MHz	TV 32
FJ	581.725	MHz	TV 32
FK	583.000	MHz	TV 32
FL	585.700	MHz	TV 33
FM	588.050	MHz	TV 33
FN	589.025	MHz	TV 33

available, use the following frequency codes. (All are compatible)			
Compatibility Group 5			This frequency is in US TV Channel:
FL	585.700	MHz	TV 33
FM	588.050	MHz	TV 33
FN	589.025	MHz	TV 33
FP	591.125	MHz	TV 34
FR	591.650	MHz	TV 34
FS	592.850	MHz	TV 34

If TV Channels 33 & 34 are open /