

Using a Third-Party Control System

Control Systems

The microphone receives logic commands over the network. Many parameters controlled through the web application can be controlled through a third party control system, using the appropriate command string.

Common applications:

- Mute
- LED color and behavior
- Loading presets
- Adjusting levels

A complete list of command strings is available in the device help or from www.shure.com.

MXA910 Microflex® Advance™ Command Strings

Command Strings

The device is connected via Ethernet to a control system, such as AMX, Crestron or Extron.

Connection: Ethernet (TCP/IP; select "Client" in the AMX/Crestron program)

Port: 2202

Conventions

The device has 4 types of strings:

GET
Finds the status of a parameter. After the AMX/Crestron sends a GET command, the MXA910 responds with a REPORT string

SET
Changes the status of a parameter. After the AMX/Crestron sends a SET command, the MXA910 will respond with a REPORT string to indicate the new value of the parameter.

REP
When the MXA910 receives a GET or SET command, it will reply with a REPORT command to indicate the status of the parameter. REPORT is also sent by the device when a parameter is changed on the MXA910 or through the GUI.

SAMPLE
Used for metering audio levels.

All messages sent and received are ASCII. Note that the level indicators and gain indicators are also in ASCII

Most parameters will send a REPORT command when they change. Thus, it is not necessary to constantly query parameters. The MXA910 will send a REPORT command when any of these parameters change.

The character "x" in all of the following strings represents the channel of the MXA910 and can be ASCII numbers 0 through 9 as in the following table.

0	All channels
1 through 8	Individual channels
9	Automix output

Command Strings (Common)

Get All		
	Command String: < GET x ALL >	Where x is ASCII channel number: 0 through 9. Use this command on first power on to update the status of all parameters.
	MXA910 Response: < REP ... >	The MXA910 responds with individual Report strings for all parameters.
Get Model Number		
	Command String: < GET MODEL >	
	MXA910 Response: < REP MODEL {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} >	Where yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy is 32 characters of the model number. The MXA910 always responds with a 32 character model number.

Get Serial Number	
Command String: < GET SERIAL_NUM >	
MXA910 Response: < REP SERIAL_NUM {XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX} >	Where xx is 32 characters of the serial number. The MXA910 always responds with a 32 character serial number.
Get Firmware Version	
Command String: < GET FW_VER >	
MXA910 Response: < REP FW_VER {XXXXXXXXXXXXXXXXXXXX} >	Where xxxxxxxxxxxxxxxxxxxxxxx is 18 characters. The MXA910 always responds with 18 characters.
Get Audio IP Address	
Command String: < GET IP_ADDR_NET_AUDIO_PRIMARY >	
MXA910 Response: < REP IP_ADDR_NET_AUDIO_PRIMARY {XXXXXXXXXXXXXXXXXX} >	Where xxxxxxxxxxxxxxx is a 15 digit IP address.
Get Audio Subnet Address	
Command String: < GET IP_SUBNET_NET_AUDIO_PRIMARY >	
MXA910 Response: < REP IP_SUBNET_NET_AUDIO_PRIMARY {XXXXXXXXXXXXXXXXXX} >	Where xxxxxxxxxxxxxxx is a 15 digit subnet address.
Get Audio Gateway Address	
Command String: < GET IP_GATEWAY_NET_AUDIO_PRIMARY >	
MXA910 Response: < REP IP_GATEWAY_NET_AUDIO_PRIMARY {XXXXXXXXXXXXXXXXXX} >	Where xxxxxxxxxxxxxxx is a 15 digit gateway address.
Get Channel Name	
Command String: < GET x CHAN_NAME >	Where x is ASCII channel number: 0 through 9.
MXA910 Response: < REP x CHAN_NAME {XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX} >	Where xx is 31 characters of the channel name. The MXA910 always responds with a 31 character name.
Get Device ID	
Command String: < GET DEVICE_ID >	The Device ID command does not contain the x channel character, as it is for the entire device.
MXA910 Response: < REP DEVICE_ID {XXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXXX} >	Where xx is 31 characters of the device ID. The MXA910 always responds with a 31 character device ID.
Get Audio Gain	
Command String: < GET x AUDIO_GAIN_HI_RES >	Where x is ASCII channel number: 1 through 9. Channel number 0 (all channels) is not valid for this command.
MXA910 Response: < REP x AUDIO_GAIN_HI_RES yyyy >	Where yyyy takes on the ASCII values of 0000 to 1400. yyyy is in steps of one-tenth of a dB.
Set Audio Gain	
Command String: < SET x AUDIO_GAIN_HI_RES yyyy >	Where yyyy takes on the ASCII values of 0000 to 1400. yyyy is in steps of one-tenth of a dB.

	<p>MXA910 Response:</p> <p>< REP x AUDIO_GAIN_HI_RES yyyy ></p>	Where yyyy takes on the ASCII values of 0000 to 1400.
Increase Audio Gain by n dB		
	<p>Command String:</p> <p>< SET x AUDIO_GAIN_HI_RES INC nn ></p>	Where nn is the amount in one-tenth of a dB to increase the gain. nn can be single digit (n), double digit (nn), triple digit (nnn).
	<p>MXA910 Response:</p> <p>< REP x AUDIO_GAIN_HI_RES yyyy ></p>	Where yyyy takes on the ASCII values of 0000 to 1400.
Decrease Audio Gain by n dB		
	<p>Command String:</p> <p>< SET x AUDIO_GAIN_HI_RES DEC nn ></p>	Where nn is the amount in one-tenth of a dB to decrease the gain. nn can be single digit (n), double digit (nn), triple digit (nnn).
	<p>MXA910 Response:</p> <p>< REP x AUDIO_GAIN_HI_RES yyyy ></p>	Where yyyy takes on the ASCII values of 0000 to 1400.
Get Channel Audio Mute		
	<p>Command String:</p> <p>< GET x AUDIO_MUTE ></p>	Where x is ASCII channel number: 0 through 9. Channel Audio Mute is pre-meter
	<p>MXA910 Response:</p> <p>< REP x AUDIO_MUTE ON ></p> <p>< REP x AUDIO_MUTE OFF ></p>	The MXA910 will respond with one of these strings.
Mute Channel Audio		
	<p>Command String:</p> <p>< SET x AUDIO_MUTE ON ></p>	
	<p>MXA910 Response:</p> <p>< REP x AUDIO_MUTE ON ></p>	
Unmute Channel Audio		
	<p>Command String:</p> <p>< SET x AUDIO_MUTE OFF ></p>	
	<p>MXA910 Response:</p> <p>< REP x AUDIO_MUTE OFF ></p>	
Toggle Channel Audio Mute		
	<p>Command String:</p> <p>< SET x AUDIO_MUTE TOGGLE ></p>	
	<p>MXA910 Response:</p> <p>< REP x AUDIO_MUTE ON ></p> <p>< REP x AUDIO_MUTE OFF ></p>	The MXA910 will respond with one of these strings.
Get Device Audio Mute		
	<p>Command String:</p> <p>< GET DEVICE_AUDIO_MUTE ></p>	Device Audio Mute is post-meter.
	<p>MXA910 Response:</p> <p>< REP DEVICE_AUDIO_MUTE ON ></p> <p>< REP DEVICE_AUDIO_MUTE OFF ></p>	The MXA910 will respond with one of these strings.
Mute Device Audio		
	<p>Command String:</p> <p>< SET DEVICE_AUDIO_MUTE ON ></p>	
	<p>MXA910 Response:</p> <p>< REP DEVICE_AUDIO_MUTE ON ></p>	

Unmute Device Audio	
<p>Command String: < SET DEVICE_AUDIO_MUTE OFF ></p>	
<p>MXA910 Response: < REP DEVICE_AUDIO_MUTE OFF ></p>	
Toggle Device Audio Mute	
<p>Command String: < SET DEVICE_AUDIO_MUTE TOGGLE ></p>	
<p>MXA910 Response: < REP DEVICE_AUDIO_MUTE ON > < REP DEVICE_AUDIO_MUTE OFF ></p>	<p>The MXA910 will respond with one of these strings.</p>
Get Output Clip Status	
<p>Command String: < GET x AUDIO_OUT_CLIP_INDICATOR ></p>	<p>Where x is ASCII channel number: 0 through 9. It is not necessary to continually send this command. The MXA910 will send a REPORT message whenever the status changes.</p>
<p>MXA910 Response: < REP x AUDIO_OUT_CLIP_INDICATOR ON > < REP x AUDIO_OUT_CLIP_INDICATOR OFF ></p>	<p>The MXA910 will respond with one of these strings.</p>
Flash Lights on Microphone	
<p>Command String: < SET FLASH ON > < SET FLASH OFF ></p>	<p>Send one of these commands to the MXA910. The flash automatically turns off after 30 seconds.</p>
<p>MXA910 Response: < REP FLASH ON > < REP FLASH OFF ></p>	<p>The MXA910 will respond with one of these strings.</p>
Turn Metering On	
<p>Command String: < SET METER_RATE sssss ></p>	<p>Where sssss is the metering speed in milliseconds. Setting sssss=0 turns metering off. Minimum setting is 100 milliseconds. Metering is off by default.</p>
<p>MXA910 Response: < REP METER_RATE sssss > < SAMPLE aaa bbb ccc ddd eee fff ggg hhh iii ></p>	<p>Where aaa, bbb, etc is the value of the audio level received and is 000-060. aaa = output 1 bbb = output 2 ccc = output 3 ddd = output 4 eee = output 5 fff = output 6 ggg = output 7 hhh = output 8 iii = output 9</p>
Stop Metering	
<p>Command String: < SET METER_RATE 0 ></p>	<p>A value of 00000 is also acceptable.</p>
<p>MXA910 Response: < REP METER_RATE 00000 ></p>	
Get Audio Peak Level	
<p>Command String: < GET x AUDIO_IN_PEAK_LVL ></p>	

<p>MXA910 Response: < REP x AUDIO_IN_PEAK_LVL nnn ></p>	<p>Where nnn is the audio level and is 000-060.</p>
Get Audio RMS Level	
<p>Command String: < GET x AUDIO_IN_RMS_LVL ></p>	
<p>MXA910 Response: < REP x AUDIO_IN_RMS_LVL nnn ></p>	<p>Where nnn is the audio level and is 000-060.</p>
Get Preset	
<p>Command String: < GET PRESET ></p>	
<p>MXA910 Response: < REP PRESET nn ></p>	<p>Where nn is the preset number 01-10.</p>
Set Preset	
<p>Command String: < SET PRESET nn ></p>	<p>Where nn is the preset number 1-10. (Leading zero is optional when using the SET command).</p>
<p>MXA910 Response: < REP PRESET nn ></p>	<p>Where nn is the preset number 01-10.</p>
Get Preset Name	
<p>Command String: < GET PRESET1 > < GET PRESET2 > < GET PRESET3 > etc</p>	<p>Send one of these strings to the MXA910.</p>
<p>MXA910 Response: < REP PRESET1 {YYYYYYYYYYYYYYYYYYYYYYYYYYY} > < REP PRESET2 {YYYYYYYYYYYYYYYYYYYYYYYYYYY} > < REP PRESET3 {YYYYYYYYYYYYYYYYYYYYYYYYYYY} > etc</p>	<p>WhereYYYYYYYYYYYYYYYYYYYYYYYYYYY is 25 characters of the preset name. The MXA910 always responds with a 25 character preset name</p>
Get Gate Out Status	
<p>Command String: < GET x AUTOMIX_GATE_OUT_EXT_SIG ></p>	<p>Where x is ASCII channel number: 0 through 8. It is not necessary to continually send this command. The MXA910 will send a REPORT message whenever the status changes.</p>
<p>MXA910 Response: < REP x AUTOMIX_GATE_OUT_EXT_SIG ON > < REP x AUTOMIX_GATE_OUT_EXT_SIG OFF ></p>	<p>The MXA910 will respond with one of these strings.</p>
Get LED State	
<p>Command String: < GET DEV_LED_IN_STATE ></p>	
<p>MXA910 Response: < REP DEV_LED_IN_STATE OFF > < REP DEV_LED_IN_STATE ON ></p>	<p>The MXA910 will respond with one of these strings.</p>
Set LED State	
<p>Command String: < SET DEV_LED_IN_STATE OFF > < SET DEV_LED_IN_STATE ON ></p>	<p>Send one of these commands to the MXA910.</p>

	<p>MXA910 Response: < REP DEV_LED_IN_STATE OFF > < REP DEV_LED_IN_STATE ON ></p>	The MXA910 will respond with one of these strings.
Get LED Brightness		
	<p>Command String: < GET LED_BRIGHTNESS ></p>	
	<p>MXA910 Response: < REP LED_BRIGHTNESS n ></p>	<p>Where n can take on the following values: 0 = LED disabled 1 = LED dim 2 = LED default</p>
Set LED Brightness		
	<p>Command String: < SET LED_BRIGHTNESS n ></p>	<p>Where n can take on the following values: 0 = LED disabled 1 = LED dim 2 = LED default</p>
	<p>MXA910 Response: < REP LED_BRIGHTNESS n ></p>	
Get LED Mute Color		
	<p>Command String: < GET LED_COLOR_MUTED ></p>	
	<p>MXA910 Response: < REP LED_COLOR_MUTED nnnn ></p>	<p>Where nnnn can be RED, GREEN, BLUE, PINK, PURPLE, YELLOW, ORANGE, or WHITE</p>
Set LED Mute Color		
	<p>Command String: < SET LED_COLOR_MUTED nnnn ></p>	<p>Where nnnn can be RED, GREEN, BLUE, PINK, PURPLE, YELLOW, ORANGE, or WHITE</p>
	<p>MXA910 Response: < REP LED_COLOR_MUTED nnnn ></p>	
Get LED Unmute Color		
	<p>Command String: < GET LED_COLOR_UNMUTED ></p>	
	<p>MXA910 Response: < REP LED_COLOR_UNMUTED nnnn ></p>	<p>Where nnnn can be RED, GREEN, BLUE, PINK, PURPLE, YELLOW, ORANGE, or WHITE</p>
Set LED Unmute Color		
	<p>Command String: < SET LED_COLOR_UNMUTED nnnn ></p>	<p>Where nnnn can be RED, GREEN, BLUE, PINK, PURPLE, YELLOW, ORANGE, or WHITE</p>
	<p>MXA910 Response: < REP LED_COLOR_UNMUTED nnnn ></p>	
Get LED Mute Flashing		
	<p>Command String: < GET LED_STATE_MUTED ></p>	
	<p>MXA910 Response: < REP LED_STATE_MUTED nnn ></p>	<p>Where nnn can be ON, OFF, or FLASHING</p>
Set LED Mute Flashing		
	<p>Command String: < SET LED_STATE_MUTED nnn ></p>	<p>Where nnn can be ON, OFF, or FLASHING</p>
	<p>MXA910 Response: < REP LED_STATE_MUTED nnn ></p>	
Get LED Unmute Flashing		

	<p>Command String: < GET LED_STATE_UNMUTED ></p>	
	<p>MXA910 Response: < REP LED_STATE_UNMUTED nnn ></p>	Where nnn can be ON, OFF, or FLASHING
Set LED Unmute Flashing		
	<p>Command String: < SET LED_STATE_UNMUTED nnn ></p>	Where nnn can be ON, OFF, or FLASHING
	<p>MXA910 Response: < REP LED_STATE_UNMUTED nnn ></p>	
Get X-Axis Beam (Lobe) Steering		
	<p>Command String: < GET x BEAM_X ></p>	Where the X-Axis is parallel with the Shure logo.
	<p>MXA910 Response: < REP x BEAM_X nnnn ></p>	Where nnnn is 0000-3048 in centimeters. The value 1524 is the centerline of the MXA910.
Set X-Axis Beam (Lobe) Steering		
	<p>Command String: < SET x BEAM_X nnnn ></p>	Where nnnn is 0000-3048 in centimeters. The value 1524 is the centerline of the MXA910.
	<p>MXA910 Response: < REP x BEAM_X nnnn ></p>	
Get Y-Axis Beam (Lobe) Steering		
	<p>Command String: < GET x BEAM_Y ></p>	Where the Y-Axis is perpendicular to the X-Axis.
	<p>MXA910 Response: < REP x BEAM_Y nnnn ></p>	Where nnnn is 0000-3048 in centimeters. The value 1524 is the centerline of the MXA910.
Set Y-Axis Beam (Lobe) Steering		
	<p>Command String: < SET x BEAM_Y nnnn ></p>	Where nnnn is 0000-3048 in centimeters. The value 1524 is the centerline of the MXA910.
	<p>MXA910 Response: < REP x BEAM_Y nnnn ></p>	
Get Beam (Lobe) Height		
	<p>Command String: < GET x BEAM_Z ></p>	Where height is the distance down from the MXA910.
	<p>MXA910 Response: < REP x BEAM_Z nnn ></p>	Where nnn is 000-914 in centimeters.
Set Beam (Lobe) Height		
	<p>Command String: < SET x BEAM_Z nnn ></p>	Where nnn is 000-914 in centimeters.
	<p>MXA910 Response: < REP x BEAM_Z nnn ></p>	
Get Beam (Lobe) Width		
	<p>Command String: < GET x BEAM_W ></p>	
	<p>MXA910 Response: < REP x BEAM_W nnnn ></p>	Where nnnn can be WIDE, MEDIUM, or NARROW
Set Beam (Lobe) Width		

	<p>Command String: < SET x BEAM_W nnnn ></p>	Where nnnn can be WIDE, MEDIUM, or NARROW
	<p>MXA910 Response: < REP x BEAM_W nnnn ></p>	
Reboot MXA910 (firmware > v2.0)		
	<p>Command String: < SET REBOOT ></p>	
	<p>MXA910 Response:</p>	The MXA910 does not send a response for this command
Get Error Events (firmware > v2.0)		
	<p>Command String: < GET LAST_ERROR_EVENT ></p>	
	<p>MXA910 Response: < REP LAST_ERROR_EVENT {yyyyyy} ></p>	Where yyyy can be up to 128 characters.
Get Low Shelf Filter (firmware > v2.0)		
	<p>Command String: < GET LOW_SHELF_FILTER ></p>	
	<p>MXA910 Response: < REP LOW_SHELF_FILTER ON > < REP LOW_SHELF_FILTER OFF ></p>	The MXA910 will respond with one of these strings.
Set Low Shelf Filter (firmware > v2.0)		
	<p>Command String: < SET LOW_SHELF_FILTER ON > < SET LOW_SHELF_FILTER OFF > < SET LOW_SHELF_FILTER TOGGLE ></p>	Send on of these commands to the MXA910
	<p>MXA910 Response: < REP LOW_SHELF_FILTER ON > < REP LOW_SHELF_FILTER OFF ></p>	The MXA910 will respond with one of these strings.
	<p>Command String: < SET LOW_SHELF_FILTER ></p>	
	<p>MXA910 Response: < REP LOW_SHELF_FILTER ON > < REP LOW_SHELF_FILTER OFF ></p>	The MXA910 will respond with one of these strings.
Get Network Audio Device Name		
	<p>Command String: < GET NA_DEVICE_NAME ></p>	
	<p>MXA910 Response: < REP NA_DEVICE_NAME {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></p>	Where {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} is a text string. Most devices allow device id to be up to 31characters. Value is padded with spaces as needed to ensure that 31 char are always reported.
Get Network Audio Channel Name		
	<p>Command String: < GET xx NA_CHAN_NAME ></p>	Where xx is channel number All channels: 0 MXA910: 1-9, 9 being automix channel
	<p>MXA910 Response: < REP xx NA_CHAN_NAME {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} ></p>	Where xx is channel number. Where {yyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyyy} is 31 char channel name. Value is padded with spaces as needed to ensure that 31 char are always reported.
Get Control Network MAC Address		

	<p>Command String: < GET CONTROL_MAC_ADDR ></p>	
	<p>MXA910 Response: < REP CONTROL_MAC_ADDR yy:yy:yy:yy:yy:yy ></p>	<p>Where yy:yy:yy:yy:yy:yy is a 17 char literal string formatted as 6 octets, each separated by a colon. Example: 00:0E:DD:FF:F1:63</p>
Get Device Mute LED State		
	<p>Command String: < GET DEV_MUTE_STATUS_LED_STATE ></p>	
	<p>MXA910 Response: < REP DEV_MUTE_STATUS_LED_STATE ON > < REP DEV_MUTE_STATUS_LED_STATE OFF ></p>	<p>ON = MUTED OFF = UNMUTED</p>
Restore Default Settings (firmware > v2.0)		
	<p>Command String: < SET DEFAULT_SETTINGS ></p>	<p>Request the device to set itself to default settings.</p>
	<p>MXA910 Response: < REP PRESET xx ></p>	<p>where xx = 00 if restore is successful</p>
Get Active Mic Channels		
	<p>Command String: < GET NUM_ACTIVE_MICS ></p>	
	<p>MXA910 Response: < REP NUM_ACTIVE_MICS x ></p>	<p>where x is number of active channels that takes on values: MXA910: channels 1-8</p>
Get PEQ Filter Enable (firmware > v2.0)		
	<p>Command String: < GET xx PEQ yy ></p>	<p>Where xx is the PEQ block 01-04. Where yy is the PEQ filter 01-04 within the block. 00 can be used for all blocks or all filters.</p>
	<p>MXA910 Response: < REP xx PEQ yy ON > < REP xx PEQ yy OFF ></p>	
Set PEQ Filter Enable (firmware > v2.0)		
	<p>Command String: < SET xx PEQ yy ON > < SET xx PEQ yy OFF ></p>	<p>Send one of these commands to the MXA910.</p>
	<p>MXA910 Response: < REP xx PEQ yy ON > < REP xx PEQ yy OFF ></p>	<p>Where xx is the PEQ block 01-04. Where yy is the PEQ filter 01-04 within the block. 00 can be used for all blocks or all filters.</p>
Get Automix Channel Solo Enable		
	<p>Command String: < GET x CHAN_AUTOMIX_SOLO_EN ></p>	<p>where x is channel number: 0 is not valid MXA910: channels 1-8</p>
	<p>MXA910 Response: < REP x CHAN_AUTOMIX_SOLO_EN ENABLE > < REP x CHAN_AUTOMIX_SOLO_EN DISABLE ></p>	<p>where x is channel number: 0 is not valid MXA910: channels 1-8; where sts indicates channel x's SOLO state: ENABLE DISABLE</p>
Set Automix Channel Solo Enable		
	<p>Command String: < SET x CHAN_AUTOMIX_SOLO_EN ENABLE > < SET x CHAN_AUTOMIX_SOLO_EN DISABLE ></p>	<p>where x is channel number: 0 is not valid MXA910: channels 1-8; where sts determines the requested state of SOLO mode: ENABLE DISABLE</p>
	<p>MXA910 Response: < REP x CHAN_AUTOMIX_SOLO_EN ENABLE > < REP x CHAN_AUTOMIX_SOLO_EN DISABLE ></p>	<p>where x is channel number: 0 is not valid MXA910: channels 1-8; where sts indicates channel x's SOLO state: ENABLE DISABLE</p>

Get Encryption Status (firmware > v2.0)	
Command String: < GET ENCRYPTION >	Get device level encryption status;
MXA910 Response: < REP ENCRYPTION ON > < REP ENCRYPTION OFF >	Send one of these commands to the MXA910.